

# Easytop concealed straight seat valve with SC-Contur

## Instructions for Use



for drinking water installation

**Model**  
5335

**Year built:**  
from 02/2015

en\_INT

**viega**



# Table of contents

<b>1</b>	<b>About these instructions for use</b>	<b>4</b>
1.1	Target groups	4
1.2	Labelling of notes	4
1.3	About this translated version	5
<b>2</b>	<b>Product information</b>	<b>6</b>
2.1	Intended use	6
2.1.1	Areas of use	6
2.1.2	Media	6
2.2	Product description	6
2.2.1	Overview	7
2.2.2	Press connection with SC-Contur	8
2.2.3	Markings on components	8
2.2.4	Compatible components	8
2.2.5	Technical data	9
2.3	Information for use	10
2.3.1	Corrosion	10
2.4	Optional accessories	10
<b>3</b>	<b>Handling</b>	<b>14</b>
3.1	Assembly information	14
3.1.1	Installation dimensions	14
3.1.2	Mounting instructions	14
3.1.3	Required tools	15
3.2	Assembly	16
3.2.1	Shortening the pipes	16
3.2.2	Pressing the connection	17
3.2.3	Mounting the valve	17
3.2.4	Leakage test	19
3.3	Maintenance	19
3.4	Disposal	19

# 1 About these instructions for use

Trade mark rights exist for this document, further information can be found at [www.viega.com/legal-notice](http://www.viega.com/legal-notice).

## 1.1 Target groups

The information in this manual is directed at heating and sanitary professionals and trained personnel.

It is not permitted for individuals without the abovementioned training or qualification to mount, install and, if required, service this product. This restriction does not extend to possible operating instructions.

The installation of Viega products must take place in accordance with the general rules of engineering and the Viega instructions for use.

## 1.2 Labelling of notes

Warning and advisory texts are set aside from the remainder of the text and are labelled with the relevant pictographs.



### **DANGER!**

This symbol warns against possible life-threatening injury.



### **WARNING!**

This symbol warns against possible serious injury.



### **CAUTION!**

This symbol warns against possible injury.



### **NOTICE!**

This symbol warns against possible damage to property.



*Notes give you additional helpful tips.*

### 1.3 About this translated version

This instruction for use contains important information about the choice of product or system, assembly and commissioning as well as intended use and, if required, maintenance measures. The information about the products, their properties and application technology are based on the current standards in Europe (e. g. EN) and/or in Germany (e. g. DIN/DVGW).

Some passages in the text may refer to technical codes in Europe/Germany. These should serve as recommendations in the absence of corresponding national regulations. The pertinent national laws, standards, regulations and guidelines, as well as other technical guidelines, have priority over German/European guidelines in this manual: The information is not binding for other countries and territories and should, as mentioned, be considered as support.

## 2 Product information

### 2.1 Intended use



*The use of the model for areas of use and media other than those described must be approved by the Viega Service Center.*

#### 2.1.1 Areas of use

Use is possible in the following areas among others:

- Drinking water installations
  - with Raxofix PE-Xc/Al/PE-Xc pipes (dimensionally stable with external oxygen seal coat)
  - with Raxofix PE-Xc pipes (flexible without external oxygen seal coat)

The model serves as a shut-off for the storey units.

The general rules of engineering must be observed for planning, execution, operation and maintenance of drinking water installations.

E. g. the following regulations apply:

- DIN EN 806 Part 1–5 and DIN EN 1717
- Supplementary national regulations amongst others DIN 1988, VDI/DVGW 6023 and Drinking Water Ordinance (DWO)

#### 2.1.2 Media

The model is suitable for the following media, among others:

- Drinking water without limitations  
in acc. with DWO
- max. chloride concentration 250 mg/l  
in acc. with DWO

### 2.2 Product description

Easytop system fittings can be used for all types of drinking water in acc. with DWO and DIN 50930-6 and are DVGW certified. Their plastic components conform with the KTW recommendation and the requirements of the DVGW Worksheet W 270.

## 2.2.1 Overview



The Easytop system fittings comply with the testing criteria of DIN EN 1213: 1999 (Fitting group I).  
Sound protection  $L_{ap} \leq 20$  dB(A)




Fig. 1: Installation of a straight seat valve with model 2235 as an example

- 1 - Easytop concealed straight seat valve
- 2 - protective sleeve
- 3 - driver
- 4 - protective cap

The model is equipped as follows:

- upper part
- site protection
- valve casing made of gunmetal
- valve seat made of stainless steel
- dual-sided Raxofix press connection with SC-Contur
- green dot for drinking water

The model is available in the following dimensions: d 16 / 20 / 25 / 32.

## 2.2.2 Press connection with SC-Contur

### SC-Contur



Fig. 2: SC-Contur

Viega press connections are equipped with the SC-Contur. The SC-Contur is a safety technology that is certified by the DVGW and ensures that the connection is guaranteed to be leaky in an unpressed state. In this way, unpressed connections are noticed immediately during a leakage test.

Viega guarantees that unpressed connections are visible during a leakage test:

- with the wet leakage test in the pressure range from 0.1–0,65 MPa (1.0–6.5 bar)
- with dry leakage test in the pressure range from 22 hPa–0.3 MPa (22 mbar–3.0 bar)

## 2.2.3 Markings on components

The press connections are marked with a coloured dot. This identifies the SC-Contur, where the test medium would escape in the case of an inadvertently unpressed connection.

The model is marked as follows:

- Flow direction indicator
- Noise class I in acc. with DIN EN 1213
- Dimension
- DWGW writing
- green dot for drinking water
- Position indicator

## 2.2.4 Compatible components

The model is equipped with Raxofix press connections and compatible with the Raxofix system.

## Pipes

Raxofix plastic pipes are available as a coiled bundle with and without protective pipe as well as with various thicknesses of insulation. Dimensionally stable multilayer pipes are also available in rods 5 m long. The following pipes are available:

- **Raxofix PE-Xc/Al/Pe-Xc**
  - dimensionally stable
  - with external oxygen seal coat
  - d 16, 20, 25, 32
- **Raxofix PE-Xc**
  - flexible
  - without external oxygen seal coat
  - d 16, 20

### 2.2.5 Technical data

Observe the following operating conditions for the installation of the model:

Operating temperature [ $T_{max}$ ]	70 °C
Operating pressure [ $P_{max}$ ]	1.0 MPa (10 bar)

## 2.3 Information for use

### 2.3.1 Corrosion

Overground pipelines and fittings in rooms do not normally require external corrosion protection.

There are exceptions in the following cases:

- Contact with aggressive building materials such as nitrite or materials containing ammonium
- Contact with aggressive chemicals
- in aggressive surroundings

If external corrosion protection is required, the following regulations should be followed:

- DIN EN 806-2
- DIN 1988-200
- DKI information publication i. 160



*Easytop fittings made of gunmetal are suitable for all types of drinking water.*

*The chloride concentration in the medium must not exceed 250 mg/l.*

*This chloride is not a disinfectant, but in fact pertains to the content in sea and table salt (sodium chloride).*

## 2.4 Optional accessories

The following optional accessories are available:

- Insulating shell
- Equipment sets
- Public building model
- Mounting sets



*Fig. 3: 2210.40 Insulating shell*



*Fig. 4: 2236.10 Equipment set*



*Fig. 5: 2236 Equipment set*



*Fig. 6: 2236.50 Public building model*



*Fig. 7: 2235.90 Mounting set front*




*Fig. 8: 2235.95 Mounting set back*

# 3 Handling

## 3.1 Assembly information

### 3.1.1 Installation dimensions



- A - at least 45 mm
- B - maximum 130 mm  
(when using model 2236 maximum 80 mm)

### 3.1.2 Mounting instructions

#### Checking system components



*Do not remove the model from the packaging until immediately before use.*

System components may, in some cases, become damaged through transportation and storage.

- Check all parts.
- Replace damaged components.
- Do not repair damaged components.
- Contaminated components may not be installed.

#### During assembly

Observe the following when mounting the model:

- minimum / maximum installation depth
- Use suitable tools



*Choose the place of installation so that the fitting is easily accessible, simple to operate and the insulating shell can be well mounted.*

## Laying and fixing pipes

Information can be found in the Raxofix system instructions for use.

## Length expansion

Information can be found in the Raxofix system instructions for use.

### 3.1.3 Required tools

The following tools are required for production of a press connection:



*Hand or electric saws or angle grinders are not permitted.*

- Press machine with constant pressing force
- suitable Raxofix press jaw for PE-Xc systems
- Pipe shear (model 5341) for dimensions 16–25 mm
- Pipe cutters (model 2191) for dimensions 32–63 mm
- Bending tool (model 5331 or 5331.2)



Fig. 9: Raxofix, press jaws

Recommended Viega press machines:

- Pressgun 5
- Pressgun Picco
- Pressgun 4E / 4B
- Picco
- Type PT3-AH
- Type PT3-H / EH
- Type 2 (PT2)

## 3.2 Assembly

### 3.2.1 Shortening the pipes



#### NOTICE!

**Leaky press connections due to damaged material**

Press connections can become leaky due to damaged pipes.

See [↗ Chapter 3.1.3 „Required tools“ on page 15](#) for information about tools.


#### Dimensions 16–25 mm

- Cut the protective pipe to length using the protective pipe cutter (model 5341).

- Cut pipe to length properly using a pipe shear.

Make sure that the cut surface is clean and straight (see illustration on bottom right).

#### Dimensions 32–63 mm




- Cut the pipe to length properly using a pipe cutter (model 2191).


### 3.2.2 Pressing the connection




*Information regarding the intervals can be found in the Raxofix system instructions for use.*



- Push the pipe into the press connector until the pipe end is visible in the inspection window.



- Check insertion depth in the inspection window.



- Open press jaw and place at a right-angle onto the connector. Start pressing.
  - ⇒ Connection is pressed.

### 3.2.3 Mounting the valve



*A functionality test must be carried out after mounting.*

Installation is possible in masonry (wet construction) and in dry constructions (pre-wall / duct installations).

### Attaching in dry constructions



Fig. 10: 2235.95 Fixing set back

- Attach the fitting from behind with the fixing set onto a Viega fitting holder with slot nuts.
- Seal wall lead-in on the front side of the wall with the self-adhesive sealing flange.




Fig. 11: 2235.90 Fixing set front

- Attach the protective sleeve of the valve in front of and behind the cladding (e. g. sheetrock or Fermacell panels) with lock nuts.
- Seal wall lead-in on the front side of the wall with the self-adhesive sealing flange.

### Actuating the valve

- Open or close the valve clockwise or anti-clockwise respectively.
- During the preliminary building work phases:  
Actuate the valve via the protective cap.

### 3.2.4 Leakage test

The installer must perform a leakage test before commissioning.

This test is carried out on a unit that is finished but not yet covered.

The general rules of engineering must be observed.

E. g. the following regulations apply:

- DIN EN 806-4

The result must be documented.

## 3.3 Maintenance



### NOTICE!

Inform your customer or the operator of the drinking water installation that the system has to be maintained on a regular basis.

DIN EN 806-5 must be observed for the operation and maintenance of drinking water installations.



*We recommend actuating the fitting regularly and checking its function.*

## 3.4 Disposal

Separate the product and packaging materials (e. g. paper, metal, plastic or non-ferrous metals) and dispose of in accordance with valid national legal requirements.