INT

Instructions for Use

WC cover plate for Prevista Visign for Style



for all Prevista concealed cisterns

Model	Year built (from)
8660.1	11/2022

Table of contents

1 **About these instructions for use** 3

1.1 Target groups 3
1.2 Labelling of notes 3
1.3 About this translated version 4

2 **Product information** 5

2.1 Intended use 5
2.1.1 Areas of application 5

2.2 Product description 6
2.2.1 Overview 6

3 **Handling** 7

3.1 Assembly 7
3.1.1 Mounting the cover plate 7

3.2 Actuate emergency actuation 8
3.3 Care and maintenance 10
3.3.1 Care tips 10

3.4 Disposal 10

1 About these instructions for use

Trade mark rights exist for this document; for further information, go to *viega.com/legal*.

1.1 Target groups

The information in this instruction manual is directed at the following groups of people:

- Heating and plumbing experts and trained personnel

Individuals without the abovementioned training or qualification are not permitted to mount, install and, if required, maintain this product. This restriction does not extend to possible operating instructions.

The installation of Viega products must take place in accordance with the general rules of engineering and the Viega instructions for use.

1.2 Labelling of notes

Warning and advisory texts are set aside from the remainder of the text and are labelled with the relevant pictographs.

DANGER!
This symbol warns of possible life-threatening injury.

WARNING!
This symbol warns of possible serious injury.

CAUTION!
This symbol warns of possible injury.

NOTICE!
This symbol warns of possible damage to property.

This symbol gives additional information and hints.

1.3 About this translated version

This instruction for use contains important information about the choice of product or system, assembly and commissioning as well as intended use and, if required, maintenance measures. The information about the products, their properties and application technology are based on the current standards in Europe (e.g. EN) and/or in Germany (e.g. DIN/DVGW).

Some passages in the text may refer to technical codes in Europe/ Germany. These should serve as recommendations in the absence of corresponding national regulations. The relevant national laws, standards, regulations, directives and other technical provisions take priority over the German/European directives specified in this manual: The information herein is not binding for other countries and regions; as said above, they should be understood as a recommendation.

2 Product information

2.1 Intended use

2.1.1 Areas of application

The cover plate conceals the inspection shaft if flush actuation is only possible via a WC remote flush actuation.

Use the cover plate only in conjunction with the connection cable (model 8570.55), the radio receiver (model 8570.58) and the WC remote flush actuators for Prevista Visign for More 200 (model 8641.1) or Prevista Visign for Style 23 (model 8640.1).

2.2 Product description

2.2.1 Overview





Fig. 1: Overview

1 installation frame
2 Cover plate
3 Actuating rod
4 Retaining bolt


3 Handling

3.1 Assembly


3.1.1 Mounting the cover plate




- Put on the installation frame.




- Insert the retaining bolts.



- Turn the retaining bolts by 90° in a clockwise direction.




- Align the installation frame.
- To fix the retaining pins, turn the safety rings in a clockwise direction.




- Attach the cover plates.


3.2 Actuate emergency actuation




- Remove the cover plate.




- Push the actuating rod through the left opening of the installation frame as far as it will go.



- Activate the flushing with the actuating rod.



- Pull out the actuating rod.



- Attach the cover plates.

3.3 Care and maintenance

3.3.1 Care tips

Use normal soap or a mild cleaning agent for regular care and prevention of lime scale on the flush plate. Under no circumstances should scouring agent or scratching objects be used.

Strong stains can be removed using typical household cleaner. Rinse the detergent thoroughly with clear water after the prescribed exposure time. There should be no residue on the components.

3.4 Disposal

Separate the product and packaging materials (e. g. paper, metal, plastic or non-ferrous metals) and dispose of in accordance with valid national legal requirements.

Viega GmbH & Co. KG
service-technik@viega.de
viega.com

INT • 2023-03 • VPN220368